HP	原裝	代用
21	ask	ask
22	ask	ask
21+22	ask	ask
21XL	ask	ask
22XL	ask	ask
27	ask	ask
28	ask	ask
56	ask	ask
60BK	ask	ask
60C	ask	ask
60BK+C	ask	ask
60XL BK	ask	ask
60XL C	ask	ask
61BK	ask	ask
61C	ask	ask
61XL BK (實富訂3隻, 每隻減$5)	ask	ask
61XL C	ask	ask
61BK+C	ask	ask
62BK	ask	ask
62C	ask	ask
62XL BK	ask	ask
62XL C	ask	ask
63BK (實富訂3隻, 每隻減$3)	ask	ask
63C (實富訂3隻, 每隻減$3)	ask	ask
63XL BK	ask	ask
63XL C (實富訂3隻, 每隻減$5)	ask	ask
65BK	ask	ask
65C	ask	ask
65XL BK (實富訂3隻, 每隻減$3)	ask	ask
65XL C (實富訂3隻, 每隻減$3)	ask	ask
74	ask	ask
74XL	ask	ask
75	ask	ask
75XL	ask	ask
92	ask	ask
93	ask	ask
94	ask	ask
95	ask	ask
96	ask	ask
97	ask	ask
98	ask	ask
564 BK	ask	ask
564 BK PB	ask	ask
564 C/M/Y	ask	ask
564XL BK (實富訂3隻, 每隻減$3)	ask	ask
564XL BK PB	ask	ask
564XL C/M/Y	ask	ask
702	ask	ask
804BK	ask	ask
804C	ask	ask
804XL BK	ask	ask
804XL C	ask	ask
901BK	ask	ask
901XL BK	ask	ask
901C	ask	ask
905 BK	ask	ask
905XL BK	ask	ask
905 C/Y/M	ask	ask
905XL C/Y/M	ask	ask
909XL BK	ask	ask
920XL BK	ask	ask
920XL C/Y/M	ask	ask
932XL BK	ask	ask
933XL C/Y/M	ask	ask
934XL BK	ask	ask
935XL C/Y/M	ask	ask
940XL BK	ask	ask
940XL C/Y/M	ask	ask
950XL BK	ask	ask
951XL C/Y/M	ask	ask
955 BK	ask	ask
955XL BK	ask	ask
955 C/Y/M	ask	ask
955XL C/Y/M	ask	ask
975XL BK	ask	ask
975XL C/Y/M	ask	ask
CB435A	ask	ask
CB436A	ask	ask
CB540 = 125BK	ask	ask
CB541/2/3 = 125A C/M/Y	ask	ask
CE278A	ask	ask
CE285A	ask	ask
CE310A = 126A BK	ask	ask
CE311/2/3A = 126A C/M/Y	ask	ask
CE314A = 126A	ask	ask
CE320A = 128A BK	ask	ask
CE321/2/3A = 128A C/M/Y	ask	ask
CF210A = 131A	ask	ask
CF217A	ask	ask
CF226A	ask	ask
CF226X	ask	ask
CF232A = 32A	ask	ask
CF248A	ask	ask
CF279A	ask	ask
CF280A	ask	ask
CF283A	ask	ask
CF350 = 130A	ask	ask
CF351/2/3 = 130A C/M/Y	ask	ask
CF400A = 201A	ask	ask
CF400X = 201X BK	ask	ask
CF401/2/3X = 201X C/M/Y	ask	ask
CF410X	ask	ask
CF500A BK	ask	ask
CF501/2/3A = C/M/Y	ask	ask
CF510A = 204A BK	ask	ask
CF511/2/3A = 204A C/M/Y	ask	ask
Q2612A	ask	ask
Q5949A	ask	ask
Q6000A = 124A	ask	ask
Q7553A	ask	ask

Canon	原裝	代用
CL-36	ask	ask
CL-41	ask	ask
CL-741	ask	ask
CL-741XL	ask	ask
CL-746	ask	ask
CL-746XL	ask	ask
CL-811	ask	ask
CL-811XL	ask	ask
CLI-726 BK/C/Y/M	ask	ask
CLI-751XL BK/C/M/Y/GY	ask	ask
CLI-771XL BK/C/Y/M/GY	ask	ask
CLI-781XL BK/C/M/Y/PB	ask	ask
CLI-821BK/C/M/Y	ask	ask
CLI-8BK/C/Y/M	ask	ask
GI-790BK/C/Y/M	ask	ask
PG-40	ask	ask
PG-740	ask	ask
PG-740XL	ask	ask
PG-740XL幵	ask	ask
PG740XL+741XL+PP-201	ask	ask
PG-745	ask	ask
PG-745XL	ask	ask
PG-745XL 幵	ask	ask
PG-810	ask	ask
PG-810XL	ask	ask
PG-810XL幵	ask	ask
PGI-35	ask	ask
PGI-5BK	ask	ask
PGI-725BK	ask	ask
PGI-750	ask	ask
PGI-750XL	ask	ask
PGI-770	ask	ask
PGI-770XL	ask	ask
PGI-780XL BK	ask	ask
PGI-2700 BK	ask	ask
PGI-2700 C/Y/M	ask	ask
PGI-2700XL BK	ask	ask
PGI-2700XL C/Y/M	ask	ask
PGI-820	ask	ask
416BK	ask	ask
416C/Y/M	ask	ask
418BK	ask	ask
416C/Y/M	ask	ask
045 BK	ask	ask
045 C/Y/M	ask	ask
045H BK	ask	ask
045H C/Y/M	ask	ask
CRG046H BK	ask	ask
CRG046H C/Y/M	ask	ask
CRG046C/Y/M	ask	ask
CRG-303	ask	ask
CRG-312	ask	ask
CRG-318BK	ask	ask
CRG-318C/Y/M	ask	ask
CRG-325	ask	ask
CRG-328	ask	ask
CRG-331 XL BK	ask	ask
CRG-331BK	ask	ask
CRG-331C/Y/M	ask	ask
CRG-337BK	ask	ask
FX9	ask	ask
KP-108IN 色帶+相紙	ask	ask
RP-108IN 色帶+相紙	ask	ask

Epson	原裝	代用
S015506=7753	ask	ask
S015508	ask	ask
S015511=7754	ask	ask
S015589=LQ590	ask	ask
S015628=LQ690	ask	ask
S015639=LQ310	ask	ask
S050611/2/3	ask	ask
S050614	ask	ask
S050651	ask	ask
S015374	ask	ask
T020183	ask	ask
T02H183	ask	ask
T02H2/3/4	ask	ask
T1031	ask	ask
T1032/3/4	ask	ask
T1051/2/3/4=73N BK/C/M/Y	ask	ask
T1091	ask	ask
T1092/3/4	ask	ask
T1371	ask	ask
T1411	ask	ask
T1412/3/4	ask	ask
T1431	ask	ask
T1432/3/4	ask	ask
T1761	ask	ask
T1762/3/4	ask	ask
T1771	ask	ask
T1772/3/4	ask	ask
T1781	ask	ask
T1881	ask	ask
T1882/3/4	ask	ask
T1931	ask	ask
T1932/3/4	ask	ask
T1961	ask	ask
T2551	ask	ask
T2561/2/3/4	ask	ask
T2891	ask	ask
T2900	ask	ask
T320063	ask	ask
T32006H	ask	ask
T3491	ask	ask
T3492/3/4	ask	ask
T3641	ask	ask
T3642/3/4	ask	ask
T6641	ask	ask
T6642/3/4	ask	ask
T7741	ask	ask
T7921	ask	ask
T7922/3/4	ask	ask

Xerox	原裝	代用
CT201591/2/3/4	ask	ask
CT201610	ask	ask
CT201919	ask	ask
CT202329	ask	ask
CT202330	ask	ask
CT202264/5/6/7	ask	ask

Brother	原裝	代用
BT6000BK	ask	ask
BT5000 C/Y/M	ask	ask
LC37BK	ask	ask
LC37 C/M/Y	ask	ask
LC38BK	ask	ask
LC38 C/M/Y	ask	ask
LC39BK	ask	ask
LC39 C/M/Y	ask	ask
LC40BK	ask	ask
LC40C/M/Y	ask	ask
LC57BK	ask	ask
LC57 C/M/Y	ask	ask
LC67BK	ask	ask
LC67 C/M/Y	ask	ask
LC73BK	ask	ask
LC73 C/M/Y	ask	ask
LC77XL BK	ask	ask
LC77XL C/M/Y	ask	ask
LC161BK	ask	ask
LC161 C/M/Y	ask	ask
LC163BK	ask	ask
LC163 C/M/Y	ask	ask
LC261BK	ask	ask
LC261 C/M/Y	ask	ask
LC263BK	ask	ask
LC263 C/M/Y	ask	ask
LC535XL C/M/Y	ask	ask
LC539XL BK	ask	ask
LC563BK	ask	ask
LC563C/M/Y	ask	ask
LC565XL C/M/Y	ask	ask
LC567XL BK	ask	ask
LC569XL BK	ask	ask
LC663 BK	ask	ask
LC663 C/M/Y	ask	ask
LC669XL BK	ask	ask
LC665XL C/M/Y	ask	ask
LC3511 BK	ask	ask
LC3511 C/Y/M	ask	ask
LC3513 BK	ask	ask
LC3513 C/Y/M	ask	ask
LC3617 BK	ask	ask
LC3617 C/M/Y	ask	ask
LC3619 XL BK	ask	ask
LC3619 XL C/Y/M	ask	ask
DR-2125	ask	ask
DR-2255	ask	ask
DR-2355	ask	ask
DR-3215	ask	ask
DR-3355	ask	ask
TN-240 BK/C/M/Y	ask	ask
TN-261 BK	ask	ask
TN-261 C/M/Y	ask	ask
TN-265 C/M/Y	ask	ask
TN-267 BK	ask	ask
TN-348 BK	ask	ask
TN-348 C/M/Y	ask	ask
TN-359 BK	ask	ask
TN-359 C/M/Y	ask	ask
TN-2025	ask	ask
TN-2060	ask	ask
TN-2130	ask	ask
TN-2150	ask	ask
TN-2280	ask	ask
TN-2380	ask	ask
TN-2480	ask	ask
TN-3185	ask	ask
TN-3350	ask	ask
TN-3370	ask	ask
TN-3448	ask	ask
TN-351BK	ask	ask
TN-351C/Y/M	ask	ask
TZe-221	ask	ask
TZe-231	ask	ask
TZe-531	ask	ask
TZe-731	ask	ask
MK231	ask	ask
PC-402RF	ask	ask

Samsung	原裝	代用
MLT-D101S	ask	ask
MLT-D104S	ask	ask
MLT-D109S	ask	ask
MLT-D111L	ask	ask
MLT-D111S	ask	ask
MLT-D116L	ask	ask
MLT-D116S	ask	ask
MLT-D117S	ask	ask